

## ZOBOS AND SONOPHONES


### BURLESQUE BAND INSTRUMENTS

Played by the Voice

Each in a Box With Directions

No Instruction Necessary

SOLID METAL, BRASS FINISH (except No. R59 Zobo-phone), HIGHLY POLISHED



### ZOBOS

No.		Each
R 59	Zobo-phone, extra heavy cardboard, covered with red, white and blue striped paper; smooth finish, nickel-plated safety metal mouthpiece	\$0.05
R102	Zobo Cornetto, solid metal, brass finish	.25
R 3	Zobo Cornet, solid metal, brass finish. Plays first part or highest voice (Soprano or Tenor) in Zobo band, orchestra, quartet or club	1.00
R 4	Zobo Alto Cornet, solid metal, brass finish. Plays second part (Alto or Second Tenor)	1.25
R 5	Zobo Saxophone, solid metal, brass finish. Plays first bass in quartet or Zobo band	1.75
R 6	Zobo Slide Trombone with working slide, solid metal, brass finish. Plays baritone in quartet or Zobo band	4.00
R 7	Zobo Bass Horn, solid metal, brass finish. For bass voice in solo, quartet or band	4.00
R 8	Zobo Professional Cornet, solid metal, brass finish. For solo or leading voice in quartet or band. Has three working plungers—looks like genuine cornet	2.00
R 9	Zobo Professional Alto Cornet, same as No. R8, but larger. Plays second part, alto or second tenor in quartet or band	2.50
R205	Zobo Repair Package. Box containing 3 Zobo mouthpiece buttons, each with vibrator attached. (Postage, 1 ct.) Per box	.05

### DIMENSIONS OF ZOBOS

R 59—Zobo-phone, 7 inches long.	R6—Zobo Slide Trombone, 27 inches long, 7-inch bell. 34 inches long with slide fully extended.
R102—Zobo Cornetto, 5 inches long, 2½-inch bell.	R7—Zobo Bass Horn, 21 inches high, 9-inch bell.
R 3—Zobo Cornet, 11 inches long, 5½-inch bell.	R8—Zobo Professional Cornet, 11 inches long, 5½-inch bell.
R 4—Zobo Alto Cornet, 14 inches long, 6-inch bell.	R9—Zobo Professional Alto Cornet, 14 inches long, 6-inch bell.
R 5—Zobo Saxophone, 21 inches long, 6-inch bell.	

### SONOPHONES

No.		Each
R 8	Sonophone Cornet, solid metal, brass finish, 7½ inches long, 3¾-inch bell	\$0.25
R 9	Sonophone Cornet, solid metal, brass finish, 9 inches long, 4¾-inch bell	.50
R10	Sonophone Cornet, solid metal, brass finish, 12 inches long, 6-inch bell	.75
R11	Sonophone Professional Cornet, solid metal, brass finish, 9 inches long, 4¾-inch bell	1.00
R12	Sonophone Slide Trombone, with working slide, solid metal, brass finish, 12 inches long, 4¾-inch bell, slide 24 inches open, 20 inches closed	1.50
R13	Sonophone Bass Horn, solid metal, brass finish, 12 inches high, 6-inch bell	2.00
R15	Sonophone Repair Package, containing 12 vibrators. (Postage, 1 ct.)	Per package, .05

See page 6 for Shipping Weights